

# AQUATIGHT SERIES

## Installation Guide



**PPC**  
The Power of Innovation®



Cut cable squarely



Using a fixed blade prep tool in good condition, prepare cable to 1/4" x 1/4" dimensions



Ensure cable is prepared to 1/4" x 1/4" dimensions



Ensure there is no dielectric, braid or foil wrapped around center conductor



Fold back braid



If tri-shield or quad, remove outer layer of foil



Fold back inner braid



Guide center conductor and dielectric into post. Insert cable into connector until dielectric is flush with surface of post



Dielectric is flush within the post



Properly seated connector ready for compression



Visually inspect to ensure connector is fully compressed. Tighten to recommended torque.

